



# Model PBX 308

# **Extension User Guide**

# Contents

Introduction	3
Internal calls	3
Making outgoing calls	3
Making outgoing calls from Direct Dial extensions	4
Door Phone or Reception Phone	4
Transferring Calls	5
Call pick up	6
Call Diversion	6
To remove Call Diversion	7
Conference calls	7

# Introduction

The Orchid PBX 308 extensions need to Dial 9 for access to an outside Exchange Line, however, Extensions can be converted to Direct Dial by the System Administrator – Direct Dial extensions do not have to dial 9 for a line. The Direct Dial feature is ideal if you make a lot of outgoing calls and few internal calls. Direct Dial extensions need to dial \* in front of the extension number when making internal calls and when using some of the other features of the PBX 308.


### **Internal Calls**

Allows you to call another extension



#### Off Hook Dial Extension Number 201 - 208

For Direct Dial Extensions, Dial \* in front of the Extension number.



Off Hook Dial 9 and wait for External Dial Tone, dial the telephone number. Ideally, program 9 and a pause into a one touch memory.

NB: The pause is necessary in case you need to Redial a number. Direct Dial extensions just need to press Redial.

#### Making outgoing calls from Direct Dial extensions



#### Off Hook Dial the Telephone Number

Last Number Redial in "Dial 9 For a Line" mode

For last number Redial to work properly in "Dial 9 for a Line" mode you need to enter a Pause after the 9 when dialling the number. Most modern telephones have a pause button on the key-pad. Some DECT cordless phones enable you to program the phone so that "9 Pause" is inserted in front of every number dialled.

If your telephones do not have a Pause button, we recommend you contact the System Administrator to get your extension converted to "Direct Dial" Mode.

BT or Cable Select (Star) Services

Select Services (Also known as Star Services) such as Call Divert, 3 way Calling etc, can only be set up on extensions that are in "Dial 9 for a Line" mode. They cannot be set up on extensions that have been programmed for "Direct Dial" mode.

### **Door Phone or Reception Phone**

Allows you to have a conversation with a visitor at the door or reception.

If your extension has been designated to ring, it will ring like an Internal call.

If your phone has not been designated to ring when the visitor lifts the reception phone and you want to answer the call:





Off Hook Extension Dial # 7

## Transfering Calls

Allows you to manually or automatically transfer an incoming call to another extension.

To transfer manually:









Dial Recall / Extension Number

Announce Caller

If the extension wants to take the call, replace handset.

**NB:** If the Extension does not answer Replace your handset (On HOOK), in a few seconds, your phone will ring and you will be connected back with the Caller.

To transfer automatically:



Dial: Recall Extension Number



**Replace Handset** 

If the extension does not answer within 25 seconds the call will be redirected back to you and your phone will ring.

**NB:** If the Extension is engaged you will hear the Engaged tone and 2 seconds later you will be connected back with the Caller.



If your extension is not programmed to ring on incoming calls this feature allows you to pick up a call ringing on another extension.



Dial: # 7 Off Hook

For Direct Dial Extensions



### **Call Diversion**

Allows you to divert your calls temporarily to another extension.







Dial: # 0 Extension Number Off Hook

**Replace Handset** 

For Direct Dial Extensions:





Off Hook Dial: \* # 0 Extension Number

**Replace Handset** 

### **To remove Call Diversion**





Off Hook

**On Hook** 

# **Conference calls**

Allows you to set up a conference call between 2 extensions and an incoming outside call.



During the call press RECALL Dial:

Dial: \* Extension Number

If the other extension answers all three parties will be connected.

If the extension does not answer or if it is engaged, press Recall to revert back to the Caller.